

GLASS WASH 1

ALKALINE DETERGENT CLEANER

Concentrated Alkaline Detergent Cleaner

Heavy duty, non foaming alkali detergent, ideal for use in all types of glass washers for the removal of soiling and staining commonly associated with glassware and associated equipment.

Economical and versatile with multi-surface use, suitable on both hard and soft water applications. Effectively cleans with a low foaming formula. Phosphate and solvent free, and fully bio-degradable.

Suitable for use with all makes and models of glass washers and washer dryers.

Application:

1. Place feed tube into bottom of container and check automatic feed equipment is switched on.
2. Inject at 4ml per 1 litre of water at a working temperature of 45 – 60 °C.

Material Compatibility:

Glass Wash 1 is compatible with the following materials:

Stainless steel, aluminium, anodised aluminium, chromium plated material, synthetic materials, rubber, latex, glass, ceramics, copper, brass, and metal alloys.

Warnings & Cautions:

- Do not add any other chemicals, such as bleach or detergents as this may destroy the effectiveness of this product
- Wear goggles, plastic apron and rubber gloves when changing containers
- Consult the manufacturers recommended reprocessing instructions to determine cleaning agent compatibility and any additional procedures necessary to clean their particular medical device
- Store in a cool place between 5 and 25°C
- Dispose in accordance with local authority guidelines



Available in 5L and 10L